



- 1.- Gooseneck microphone connector with LED ring.
- 2.- Information display.
- 3.- **AGREE**: button to vote in favour.
- 4.- **DROP**: button to abstain.
- 5.- **DISAGREE**: button to vote against.
- 6.- +/-: increases or decreases the volume in the headphones.
- 7.- **PRIORITY**: president microphone speech priority control. By pressing this button the rest of the delegate microphones are deactivated and only the president microphone can be used.
- 8.- Microphone activation button.
- 9.- **IN/LINK**: input connector and extension for microphones **SCI-610P**, **SCI-620P** or microphone extension **SCD-630EXT**.

## DESCRIPTION

The model **SCD-610P** is a president microphone for the digital conference system mod. **SCD-600**.

## INSTALLATION

Insert the RJ-45 connector in the IN port on the rear panel and the other end of the connector in the MIC INPUT port on the control unit mod. **SCD-600**. Another delegate microphone can be connected in cascade using the LINK port, up to a maximum of 16. The maximum number of microphones can be extended up to a total of 128 in the system using the microphone extenders model **SCD-630EXT**.

**Note:** there can only be one **SCD-610P** president microphone in the system. The distance of the cables must not exceed 15 meters for an STP Cat-6 cable.

## TECHNICAL SPECIFICATIONS

	<b>SCD-610P</b>
<b>CHARACTERISTICS</b>	President microphone. Priority and control over delegate microphones. Information display. Voting buttons. Gooseneck microphone. Data and audio transmission.
<b>MICROPHONE</b>	Unidirectional electret condenser with LED ring
<b>DIMENSIONS</b>	Gooseneck microphone: 43 mm Base: 170 x 39 x 172 mm depth
<b>ACCESSORIES</b>	Foam windshield

**WARRANTY:** 2 years against manufacturing defects, accompanied by proof of purchase. Post-purchase damage or breakage is not covered.

